



## Blodgett Convection Oven Operating Instructions

**Oven operates on Propane Gas Only**  
**Oven operates on 110 Volts AC Only**

### To turn on Oven:

1. Make sure oven gas hose is attached to LP gas tank securely.
2. Make sure gas is turned on.
3. Make sure oven is plugged in.
4. Make sure the **"Red Cool Down Switch"** on the front of the oven is on **"Auto"** position.
5. Set Temperature knob to the desired setting.
6. Turn the **"Blue Blower Switch"** to the **"On"** position.
7. Before the oven pilot burner will light, all air must be purged from the pilot burner gas line!
8. You will hear a sparking sound...the oven is attempting to light the pilot burner.
- 9. It may not light on the first attempt!!!**
10. If the red indicating light does not come on in the first 45 seconds or when the sparking sound stops, turn **"Blue Blower Switch"** to **"Off"** position, wait 10 seconds, and then repeat step 6.
11. It may be necessary to repeat several times to purge pilot burner gas line.
12. When **"Red Indicating Light"** comes on, the oven is calling for heat and the burner is on.
13. When **"Red Indicating Light"** goes off, the oven is at temperature and the burner is off.
14. The **"Red Indicating Light"** will cycle on and off as the oven thermostat calls for heat.
15. When cooking is done, leave the **"Blue Blower Switch"** in the **"On"** position, turn the **"Red Cool Down Switch"** to **"Manual"** and open door to cool down the oven.
- 16. When oven is cooled down (approx 10 minutes) turn the "Blue Blower Switch" to "Off" and the "Red Cool Down Switch" to "Auto".**